



## CARBON FIBER CASE SAVER

RECCS03-CF

---

### INSTALLATION INSTRUCTIONS

The REC MX case saver is designed to be an OEM replacement. Simply remove the stock countershaft sprocket guard and stock case saver. Replace the OEM aluminum case saver with the REC MX carbon fiber one and re-insall with the guard and OEM bolts to the specified torque. \*If installing without the OEM countershaft sprocket guard, shorter 10mm bolt should be used in place of the OEM bolts. Removal of the countershaft sprocket guard is at your own risk.



---

DISCLAIMER: All REC MX products are inspected prior to packaging. Our guarantee is limited to the replacement of defective products and its components only. This limited guarantee is for manufacture defects only for 30 days from date of purchase. Buyer assumes all risk for any and all damage caused to him or herself, a third party and/or property by virtue of this product. By installing and/or using a REC MX product, you hereby accept and understand these stated terms and conditions and have followed all instructional steps. Thank you.

---