



## IGNITION WIRE GUARD

RECIG01

---

### INSTALLATION INSTRUCTIONS

The REC MX ignition wire guard simply installs using the corresponding OEM ignition cover bolts. Remove the two bolts and reinstall with the carbon fiber guard and tighten to the manufactures specified torque. Re-check the torque after the first ride and tighten as needed.



---

DISCLAIMER: All REC MX products are inspected prior to packaging. Our guarantee is limited to the replacement of defective products and its components only. This limited guarantee is for manufacture defects only for 30 days from date of purchase. Buyer assumes all risk for any and all damage caused to him or herself, a third party and/or property by virtue of this product. By installing and/or using a REC MX product, you hereby accept and understand these stated terms and conditions and have followed all instructional steps. Thank you.

---