

## INSTALLATION INSTRUCTIONS

We recommend installing your new oil filter cover when doing your next oil change.

- STEP 1: Drain the engine oil per the owner's manual.
- STEP 2: Remove the oil filter cover bolts and OEM oil filter cover.
- STEP 3: Remove the oil filter if replacing with a new filter (recommended).
- STEP 4: Inspect the OEM o-ring to make sure it is in good condition. Apply engine oil or o-ring grease to the o-ring and intall it onto the REC MX oil filter cover.
- STEP 5: Take the oil filter spring off the OEM cover and install the spring on the REC MX cover.
- STEP 6: Apply grease or engine oil to the grommet on the new oil filter and install the oil filter.
- \*make sure the grommet on the oil filter faces inward toward the engine cases.
- STEP 7: Install the new REC MX oil filter cover with the oil filter spring.
- STEP 8: Tighten the OEM oil filter cover bolts to the specified torque.
- STEP 9: Fill the engine with the recommended oil capacity.
- STEP 10: Enjoy your new oil filter cover.

