

INSTALLATION INSTRUCTIONS

We recommend installing your new filter cover when doing your next oil change.

- STEP 1: Drain the engine oil per the owner's manual.
- STEP 2: Remove the engine guard (skid plate) to access the oil filter cover bolts.
- STEP 3: Remove the OEM oil filter cover and remove the o-ring.
- STEP 4: We recommend replacing the oil filter with a new one.
- STEP 5: Apply grease to the filter end of the OEM filter spring and then install it into the new oil filter.
- STEP 6: Inspect the OEM o-ring to make sure it is in good condition. Apply engine oil or o-ring grease to the o-ring and intall it onto the REC MX oil filter cover.
- STEP 7: Install the new oil filter with spring and the REC MX cover.
- STEP 8: Tighten the OEM oil filter cover bolts to the specified torque.
- STEP 9: Install the engine guard.
- STEP 10: Fill the engine with the recommended oil and capacity.



DISCLAIMER: All REC MX products are inspected prior to packaging. Our guarantee is limited to the replacement of defective products and its components only. This limited guarantee is for manufacture defects only for 30 days from date of purchase. Buyer assumes all risk for any and all damage caused to him or herself, a third party and/or property by virtue of this product. By installing and/or using a REC MX product, you hereby accept and understand these stated terms and conditions and have followed all instructional steps. Thank you.